



- 1 Home Screen Indicator
- 2 Application Indicator
- 3 Telephone Number
- 4 Status Bar
- 5 Registration Indicator (green)
- 6 IP Address
- 7 Screen Switch
- 8 Expands Widget Bar
- 9 Quick Launch Bar
- 10 Phone Dialer/Menu
- 11 Main Menu



- 1 Call/Line Tabs - The ACN IRIS X Videophone supports up to 3 inbound/outbound simultaneous calls
- 2 Audio Controls - Speaker, Handset or Headphone Selection
- 3 Volume Output
- 4 Voice Mail - Used for both Voice and Video Mail
- 5 Once numbers have been dialed, press Audio Call or Video Call

NAVIGATION TIPS

The ACN IRIS X Videophone has an intuitive and powerful touch screen navigation with four desktop screens. To change from screen to screen, swipe the main screen to the left or right; or press to switch screens.

- ▶ **Menu** provides access to all available apps, widgets and functions.
- ▶ **Phone** displays the dial pad for voice and video calls as well as related options.
- ▶ **Widgets** are applications that can be added, moved or deleted from the desktop.
 - To modify the widget, touch the widget until **Close/Setting** options are visible.

- Additional widgets can be added to the desktop by touching and dragging from the bottom menu to the desktop.
- To view additional widgets, press to expand the Widget Bar.
- ▶ The **Home** button, located on the bottom center of the phone (below the screen), allows you to easily jump to the **Home** screen from any screen.
- ▶ The **Status Bar** provides a quick view of your phone's status. If you press the status bar, a number of options become available: Volume, Wi-Fi off/on, Network off/on (Ethernet), Do Not Disturb (DND) and Camera off/on.

USING YOUR ACN IRIS X VIDEOPHONE

Making a Call

There are several ways to make a call with your ACN IRIS X Videophone:

By Phone

- Press from the **Home** screen (or pick up the handset)
- Dial the number and press **Audio Call** or **Video Call**

By Call History

- Press from the **Home** screen
- Select **Call History**
- Select from **All, Received, Dialed** and **Missed**
- Press to call the selected number

By Contacts

- Press from the **Home** screen
- Select **Contacts**

- Select the contact you wish to dial
- Press to call the selected number

Ending a Call

Simply hang up the handset or press **End** if using the speaker phone.


Answering a Call


The screen will display the name and the number of the person calling. There are several ways to answer a call with your ACN IRIS X Videophone:

Incoming Call	Missed Call	Call Waiting
Select Accept Audio, Accept Video (if available) or Reject .	A missed call message will show up on the Home screen. Users can press View to access the details of the missed call.	While on a call, a tone and an on-screen display will alert you of an incoming call. You can Accept or Reject the call.






X CALL FUNCTION OPTIONS

While a call is in progress, several options are available. Press  **Options** to access all the call functions.

Note: While on a video call, the  **Options** menu may disappear. Press anywhere on the screen to reveal the menu.

Three menu choices will display:

Option Menu	Function	Description
	Dial Pad	Select to enter touch tone responses or to dial another number
	Hold	Press to hold the call. To take the call off hold, press Unhold
	Mute/Unmute	Press to mute or unmute the call
	Video off/on	Press to switch between Video off and Video on
	Conference	Once you have placed another call using another line, press Conference to establish a 3-way audio conference call
	Speaker/Headset/Headphone	Press one of the three options to change audio output
	Volume	Press to increase or decrease volume
	PIP	Press to switch videos between the callers and display full screen
	Snapshot	Press to take a snapshot of the current video. The snapshot will be automatically saved to the folder "screenshot" in Tools>File Manager

Support is here for you!


Additional phone features, detailed instructions and troubleshooting tips are available in the User Manual on your ACN Independent Representative's Online Shop or at www.myacn.eu

X VOICE/VIDEO MAIL

Voice/Video Mail allows callers to leave a message when you are busy or not available to take a call.

Setup/Retrieving Messages

Upon initial access to your voice mail, you will be prompted to change your password (your temporary password is 1234#). Follow the prompts to change your password, record your name and your voice/video Mail greeting, if desired.

1. Press  from the **Home** screen.
2. Press the **Voice Mail** envelope for both Voice and Video Mail.
3. Follow the prompts to listen to your Voice Mails or watch Video Mail.

Voice Mail (Message Wait Indicator)

If the **Home** button is flickering blue, this means that a voice/video mail is waiting to be retrieved. (Stutter dial tone will also be heard if the handset is picked up.) To retrieve the voice mail, activate the dial pad and then press the **Voice Mail** icon.

Quick Voice Mail Tip

To change the number of rings before the call is forwarded to voice/video mail, dial *610 and follow the prompts.

Voice Mail Functions

Several options will be available after listening to a message:

Key	Command
#	Save the message
2	Repeat the message
4	Go back to the previous message
5	Play the message header details
6	Go to the next message
7	Erase the message
*	Go back to previous menu